



## HYBRID PREMIER RECOAT SYSTEM (VFI-991/640-1) OVER AN EXISTING COATING

### 1. GENERAL SPECIFICATION:

#### 1.01. General System Description

- A. The Hybrid Premier Recoat System is recommended for existing coated roofs with unlimited slope. **See section 2 for a list of materials used in the system.** The substrate must be cleaned and primed before applying the new system for ensured adhesion. Adhesion testing is also required by embedding a portion of fabric between a wet-on-wet layer of VFI-640-1. After curing, pull the exposed half of fabric at a 90° angle to the substrate surface. The pull test should yield results of at least 4 pli for the coating adhesion to be considered acceptable.
- B. Restoring with the Hybrid Premier Recoat System will preserve and extend the useful life of the roof by protecting it from exposure to common degrading elements and weather conditions. The use of this system is restricted to circumstances where the roof surface is in sound condition but requires renewal due to the normal effects of aging and normal roof use.
- C. Specifications here include guidelines for preparation, priming, and reinforcing all seams and flashings integrally related to the roof. This is a general installation guide specification and is not a project-specific specification. It is the responsibility of the owner/building representative, project manager, and contractor to ensure that this general installation guide is followed when work pertains to the project.
- D. A Volatile Free, Inc. Technical Representative shall approve, in writing, any material substitutions, deviations from, and/or addendums to this specification.

#### 1.02. Contractor to:

- A. Provide all labor, materials, equipment, and accessories necessary to repair, clean, and prepare existing coated surfaces. Install Volatile Free, Inc.'s primer and Hybrid Premier Recoat System in accordance with this specification and the manufacturer's instructions. Reference the following sections for more detailed information.
  - 1. Environmental Requirements (1.06)
  - 2. Surface Preparation (3.02)
  - 3. Surface Wash (3.03)
  - 4. Priming (3.04)

5. Seams, Cracks, Terminations, and Penetrations (3.05)
6. Coating Application (3.06)
7. Traffic Areas and Walkways (3.07)

**1.03. Approved Materials:**

- A. Primary waterproofing materials shall be the products of a single manufacturer and produced domestically. A coating supplier must have a minimum of 10 years of experience in the manufacture of a specified product. Private-label products or materials produced outside the US are not acceptable. Secondary products shall be recommended and approved by the primary manufacturer. The coating system shall have UL Listing, Miami-Dade NOA, and Florida Building Code approval. CRRC and ENERGY STAR approvals are also required where applicable (white topcoat).
- B. Unspecified materials shall be submitted to the architect and owner/building representative for approval prior to the bid date. In requesting approval, a letter of certification must be signed by an officer of the manufacturer, stating that the alternative material is equal to or better than the specified product.

**1.04. Submittals:**

**A. Manufacturer:**

1. Provide VFI's published technical data sheets, safety data sheets, installation instructions, and certified data to support published ratings.
2. Supply warranty paperwork in accordance with application rates and requirements.

**1.05. Product Delivery, Storage, and Handling:**

- A. Deliver VFI materials in unopened containers with VFI labels affixed. Include the following on the label of each container: manufacturer's name, product name, product type, lot number, mixing instructions, and precautions.
- B. Contractors shall be responsible for the storage and protection of all materials required. Materials shall be stored in a manner so as not to exceed the VFI-specified temperature limitations (see drum label or data sheet). In all cases, the storage and handling of materials shall conform to the requirements of VFI and the applicable safety regulatory agencies.

**1.06. Environmental Requirements:**

- A. Install the coating materials under the following conditions:

1. When existing and forecasted weather conditions permit it.
2. Install VFI-991 above 40°F/4.5°C.
3. Install VFI-#11 and VFI-640-1 above 50°F/10°C.

**2. PRODUCTS:**

**2.01. Materials:**

A. All products listed are manufactured, supplied, or approved by VFI of Brookfield, WI.

1. Surface Cleaner: VFI-1009 Cleaning Detergent
2. Polyester Fabric: PF Mesh 4", 6", 12", 20", and 40" Polyester Fabric
3. Primer: VFI-#11 9:1 Epoxy Primer
4. Flashing Grade: VFI-630 Acrylic Flashing Grade
5. Base Coating: VFI-640-1 Gray Acrylic Coating

<b>VFI-640-1 Mean Technical Requirements</b>		
<b>Solids</b>	By Volume	57%
<b>Tensile</b>	ASTM D2370	201 psi
<b>Elongation</b>	ASTM D2370	574%
<b>Tear Resistance</b>	ASTM D624	84 pli
<b>Water Vapor Permeability</b>	ASTM D1653	14

6. Coating: SEALGUARD VFI-991 Silicone, in manufacturer's standard white
  - a. The system can be used with various premium and custom colors, but VFI does not guarantee color stability unless otherwise stated.

<b>VFI-991 Mean Technical Requirements</b>		
<b>Solids</b>	By Volume	64%
<b>Tensile</b>	ASTM D412	434 psi
<b>Elongation</b>	ASTM D412	246%
<b>Permanent Set</b>	ASTM D412	1% max
<b>Tear Resistance</b>	ASTM D624	41 pli
<b>Water Vapor Permeability</b>	ASTM E96 @20 MIL	9.9 perms

7. Traffic Walkways: SEALGUARD VFI-991 Silicone Walk Pad (Safety Yellow) and Granules (Safety Yellow) or Yellow Spaghetti Walk Pad provided by VFI

### **3. EXECUTION**

#### **3.01. Examination**

- A.** Identify slope and drainage patterns.
- B.** Identify existing coating type and underlying substrate to ensure compatibility with the system through an adhesion test.
- C.** Inspect for missing or loose fasteners.
- D.** Identify seam and flashing failures.
- E.** Inspect for rust and metal integrity/damage.

#### **3.02. Surface Preparation**

- A.** Remove large volumes of dirt, leaves, and other debris with a broom. Roof cement and cold-applied materials, detrimental to the adhesion and application of roofing materials, should be removed. Take care to remove all loose paint, rust, and scale.
- B.** Power wash as needed with a minimum pressure of 2,000 psi or mechanical abrasion.
- C.** The existing coated roof and its structural components must be repaired. All damaged drains, vents, ducts, gutters, metal caps, flashing, or other penetrations must be replaced or modified.
- D.** All seams should be repaired to be tight and flush. Gaps between seams shall be eliminated by applying a 3 coarse coating with fabric embedded.
- E.** Loose or backed-out fasteners must be tightened or replaced with oversized fasteners.

#### **3.03. Surface Wash:**

- A.** Areas containing grease, oil, animal fats, or other surface contaminants shall be scrubbed with non-sudsing, biodegradable liquid detergent (VFI-1009).
- B.** Use concentrated chlorine solution to treat areas of mildew, fungus, or algae.
- C.** All cleaning agents must be rinsed off the roof. Allow the roof to dry before proceeding.

#### **3.04. Priming**

- A.** Apply VFI-#11 9:1 Epoxy Primer at a rate of 0.5 gallons per square.
- B.** Allow the primer to dry for a minimum of 8 hours prior to coating. Cure time will vary depending on ambient temperature and humidity. No substrate should be exposed. The primer must be coated within 7 days after application. If the primer is not coated within 7 days, the primed surface should be cleaned and re-primed. The designed

temperature is 50°F or above. Do not apply if rain is in the forecast before a topcoat can be applied.

### **3.05. Seams, Cracks, Terminations, and Penetrations:**

- A. Membrane Seams:** Inspect membrane seams and flashing for separation or cuts and repair to their original quality as required.
- B. Flashing Details, Penetrations, and Protrusions:** Using 12" fabric, seal all roof penetrations. Apply a base coat of VFI-640-1 Gray Acrylic Coating up 6" and around the penetration. Cut skirt flashing in the fabric. Lay the fabric into the wet base coat, spreading the skirt onto the roof while setting the solid piece of fabric firmly to the penetration. Remove all wrinkles and voids in the fabric with a brush. Immediately apply a saturation coat of VFI-640-1 to cover the fabric. Next, cut a piece of fabric to fit around the penetration and cover fingers to act as a target. Apply a base coat of VFI-640-1 on the roof deck around the penetration and past the fingers of the previously complete fabric flashing. Embed the target fabric into the wet base coat. Remove all wrinkles and voids in the fabric using a brush. Immediately apply a saturation coat of VFI-640-1 to cover the target fabric.
- C. Rooftop Equipment and Curbs:** Using the appropriate size fabric, waterproof all rooftop equipment and curbs. Apply a base coat of VFI-640-1 to the area receiving fabric. Embed the fabric into the base coat while it is still wet, taking care to remove all wrinkles, voids, and fish mouths. Immediately apply a saturation coat of VFI-640-1 to cover the fabric. Terminate the fabric ¼" below existing flashings. Continue waterproofing onto the roof a minimum of 6".
- D. Backed-Out Fasteners:** Replace all fasteners that are loose or backed.

### **3.06. Coating Application**

- A.** Ensure adhesion tests are completed and meet VFI requirements.
- B.** Check wet film thickness during application with a mil gauge.
- C.** Install VFI-640-1 Gray Acrylic Coating over the entire roof surface. Embed fabric in a base coat of 1.5 gallons per square and apply a wet-on-wet coat at 1 gallon per square. Allow the acrylic coating to fully cure before applying the VFI-991 topcoat.
- D.** Install SEALGUARD VFI-991 Silicone over the entire roof surface to achieve the desired warranty requirement in DFT (Dry film thickness):
  - 1. Minimum DFT for a 10-year warranty**

- a. **Base coat of VFI-640-1 at 23 mils DFT (2.5 gallons per square)**
- b. **Top coat of VFI-991 at 21 mils DFT (2 gallons per square)**

**2. Minimum DFT for a 15-year warranty**

- a. **Base coat of VFI-640-1 at 23 mils DFT (2.5 gallons per square)**
- b. **Top coat of VFI-991 at 26 mils DFT (2.5 gallons per square)**

E. Recoat time is between 2 to 48 hours, depending on environmental conditions and cure speed. Longer recoat times may result in poor intercoat adhesion and delamination from surface contamination.

F. No traffic shall be permitted on the coated surface for a minimum of one (1) day. Damage to the surface by other trades shall not be the responsibility of the roofing contractor or Volatile Free, Inc.

**3.07. Traffic Areas and Walkways**

**A. Option 1:**

1. **Low Impact** – Apply VFI-991 Safety Yellow Walk Pad at a rate of 2 gal/sq. Broadcast Safety Yellow Granules at 40 lb/sq.
2. **High Impact** – Apply VFI-991 Safety Yellow Walk Pad at a rate of 2.5 gal/sq. Broadcast Safety Yellow Granules at 60 lb/sq.
3. **After the Walk Pad has cured, sweep away any loose or excess granules.**

**B. Option 2:** Yellow spaghetti factory-formed walkway pads are to be used in walkway areas and around rooftop equipment as identified by the owner’s representative. Spot adhere the pads or rolls to the finished roof surface with generous ribbons of silicone sealant as provided by Volatile Free, Inc.

THIS INFORMATION AND TECHNICAL ADVICE PROVIDED HEREIN ARE BELIEVED TO BE RELIABLE AND ACCURATE TO THE BEST KNOWLEDGE OF VOLATILE FREE, INC., AS BASED ON TESTS AND SHOULD SERVE ONLY AS A RECOMMENDATION. AS THE MANUFACTURER, VOLATILE FREE, INC. MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR USE OR A PARTICULAR PURPOSE FOR THE PRODUCT. VOLATILE FREE, INC. MAKES NO REPRESENTATIONS OR WARRANTIES AS TO THE RESULTS OF THE USE OF THE PRODUCT AND ASSUMES NO OBLIGATION OR LIABILITY IN CONNECTION THEREWITH. VOLATILE FREE, INC. IS NOT LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY SORT FROM USE OF THIS PRODUCT. THE INFORMATION PROVIDED HEREIN IS SUBJECT TO CHANGE AT ANYTIME WITHOUT NOTICE. INFORMATION CHANGES MAY INCLUDE, BUT ARE NOT LIMITED TO, COMMERCIAL AND TECHNICAL CHANGES, CHANGES IN PRICING, PHYSICAL CHARACTERISTICS AND PACKAGING.

Corporate Office: P.O. Box 344 . Brookfield, WI 53008 . (800) 307-9218 . (262) 787-0400 . Fax (262) 787-0500  
[www.volatilefree.com](http://www.volatilefree.com)